



Weather Station

ORDERING CODE	FREQUENCY
CKNHZD1	868,4 MHz

Weather Station is used for measuring temperature, humidity, wind & rain properties and sending the measurement values to your wireless network.

The Weather Station can measure 10 different values: two sets of temperature/humidity sensors, wind gauge with 5 sensors (direction, velocity, wind gust, temperature and wind chill) and a rain sensor. With the use of the included Weather Station USB KEY all 10 values (end points) are sent and rendered in your home wireless network.

Weather Station Key is used for receiving Wireless data packages (from Thermo/ Hygro Sensor Ch1, Thermo/ Hygro Sensor Ch2, Rain Gauge, Wind Gauge) and sends it to the Cockpit main controller.

The Key is designed to be plugged into the USB Power Adapter. Module receives data for Temperature, Wind Chill, Velocity, Wind Gust, Wind Direction, Humidity, Rain Rate and Battery Level for each Sensor.

It is designed to act as repeater in order to improve range and stability of wireless network.


Package contents:

- Weather Station USB Key
- 2 x Thermo-Hygro Sensor
- Anemometer (Wind Sensor with Solar panel)
 - Wind cups
 - Wind vane
 - Anemometer arm
 - Anemometer base
 - 4 screws
- Rain Sensor
 - Funnel shaped lid with battery hatch
 - Sensor base
 - Bucket see-saw mechanism
 - Protective screen
 - 4 screws

Weather Station USB Key

Installation

- Connect the Weather Station Key into the USB Power Supply.
- Locate the module far from metal elements.
- Locate the module in the range of wireless network and in the range of all 433 MHz sensors.



S Service button (used to add or remove module from the Cockpit system).

L LED

LED Blinking Meaning

LED is 1 second ON and 1 second OFF

The module is in exclusion mode

LED is ON

The module is in inclusion mode

LED Blinks 1 time fast

The module received data from Thermo/Hygro Sensor Ch1

LED Blinks 2 time fast

The module received data from Thermo/Hygro Sensor Ch2

LED Blinks 3 time fast

The module received data from Wind Sensor

LED Blinks 4 time fast

The module received data from Rain Sensor

Module Inclusion (Adding to wireless network)

- Connect module to USB Power Supply
- enable add/remove mode on main controller
- auto-inclusion (works for about 5 seconds after connected to power supply) or
- hold service button **S** between 1.5 and 4 seconds

NOTE: For auto-inclusion procedure, first set main controller into inclusion mode and then connect module to USB power supply.

Module Exclusion/Reset (Removing from wireless network)

- Connect module to power supply
- enable add/remove mode on main controller ,
- hold service button **S** between 4 seconds and 8 seconds

By this function, all parameters of the module are set to default values, own ID is deleted and the module will include as unsecure next time.

If service button S hold more than 1.5 and less than 4 seconds module is excluded, but configuration parameters are not set to default values and the module will include next time as it was set into the Configuration Parameter 250.

Association

Association enables Weather Station module to transfer commands inside wireless network directly (without Cockpit) to other Cockpit modules.

Associated Groups:

Group 1: Lifeline group (reserved for communication with the main controller), one node allowed.

Group 2: basic on/off (triggered when the Wind Gust of the Wind Gauge exceed the Configuration Parameter 1 Value) up to 16 nodes.

Group 3: basic on/off (triggered when the Rain rate exceed the Configuration Parameter 2 Value) up to 16 nodes.

Endpoint 1: Thermo/ Hygro Sensor Ch1 – Temperature
Group 1: Lifeline group, 0 nodes allowed.

Endpoint 1 receives Temperature data from Thermo/ Hygro Sensor on Channel 1. It is capable of receiving data in range of -199.0 °C and 199.0 °C. However, the operating temperature of the 433 MHz sensor is from -10 °C to 60 °C.

Endpoint 2: Wind Gauge – Direction

Group 1: Lifeline group, 0 nodes allowed.

Endpoint 2 receives Direction data from Wind Gauge. The data is in range of 0.0° to 360.0°.

Endpoint 3: Wind Gauge – Velocity

Group 1: Lifeline group, 0 nodes allowed.

Endpoint 3 receives wind speed data from Wind Gauge. It is capable of receiving data in range of 0.00 m/s to 88.00 m/s.

Endpoint 4: Wind Gauge – Wind gust

Group 1: Lifeline group, 0 nodes allowed.

Group 2: basic on/off (triggered when the Velocity exceed the Value of Configuration Parameter 1) up to 16 nodes.

Endpoint 4 receives wind speed data from Wind Gauge. It is capable of receiving data in range of 0.00 m/s to 88.00 m/s.

Endpoint 5: Wind Gauge – Temperature

Group 1: Lifeline group, 0 nodes allowed.

Endpoint 5 receives Temperature data from Wind Gauge. It is capable of receiving data in range of -199.0 °C and 199.0 °C. However, the operating temperature of the sensor is from -10 °C to 60 °C.

Endpoint 6: Wind Gauge – Wind Chill

Group 1: Lifeline group, 0 nodes allowed.

Endpoint 6 receives Temperature data from Wind Gauge. It is capable of receiving data in range of -199.0 °C and 199.0 °C. However, the operating temperature of the sensor is from -10 °C to 60 °C.

Endpoint 7: Rain Sensor

Group 1: Lifeline group, 0 nodes allowed.

Group 2: basic on/off (triggered when the Rain rate exceed the Configuration Parameter Value 2) up to 16 nodes.

Endpoint 7 receives and calculates rain rate. The rain rate is in range of 0.00 mm/h and 300.00 mm/h.

Endpoint 8: Thermo/ Hygro Sensor Ch1 – Humidity

Group 1: Lifeline group, 0 nodes allowed.

Endpoint 8 receives Humidity data from Thermo/ Hygro Sensor on Channel 1. The data is in range of 0% and 100%.

Endpoint 9: Thermo/ Hygro Sensor Ch2 – Temperature

Group 1: Lifeline group, 0 nodes allowed.

Endpoint 9 receives Temperature data from Thermo/ Hygro Sensor on Channel 2. It is capable of receiving data in range of -199.0 °C and 199.0 °C. However, the operating temperature of the sensor is from -10 °C to 60 °C.

Endpoint 10: Thermo/ Hygro Sensor Ch2 – Humidity

Group 1: Lifeline group, 0 nodes allowed.

Endpoint 10 receives Humidity data from Thermo/ Hygro Sensor on Channel 2. The data is in range of 0% and 100%.

Configuration parameters

Parameter No. 1 – Wind Gauge, Wind Gust Top Value

Available configuration parameter (data type is 2 Byte Dec):

- default value 1000 (10,00 m/s)
- 0 – 8800 = value from 0.00 m/s to 88.00 m/s - if the Wind Gust is Higher than the Parameter Value, a device triggers an Association.

Parameter No. 2 – Rain Gauge, Rain Rate Top Value

Available configuration parameter (data type is 2 Byte Dec):

- default value 200 (2,00 mm/h)
- 0 – 30000 = value from 0.00 mm/h to 300.00 mm/h - if the Sensor Rain Rate is Higher than the Parameter Value, a device triggers an Association

Parameter No. 3 – Wind Gauge, Wind Gust

Available configuration parameter (data type is 1 Byte Dec):

- default Value 1
- 0 - If the Wind Gust is Higher than the Parameter No. 1 Value, then a Device sends Basic Set = 0x00.

- 1 - If the Wind Gust is Higher than the Parameter No. 1 Value, then a Device sends Basic Set = 0xFF.)

Parameter No. 4 – Rain Gauge, Rain Rate

Available configuration parameter (data type is 1 Byte Dec):

- default Value 1
- 0 - If the Rain amount is Higher than the Parameter No. 2 Value, then a Device sends Basic Set = 0x00.
- 1 - If the Rain amount is Higher than the Parameter No. 2 Value, then a Device sends Basic Set = 0xFF.)

Unsolicited Report

If you enable Unsolicited Reports on the End Points, the USB Key will send data to the main controller every time it receives data from the 433MHz sensors, which are different from the previous data.

Parameter No. 5 – Endpoint 1 – Unsolicited Report

Available configuration parameter (data type is 1 Byte Dec):

- default Value 1
- 0 – Unsolicited Report disabled
- 1 – Unsolicited Report enabled

Parameter No. 6 – Endpoint 2 – Unsolicited Report

Available configuration parameter (data type is 1 Byte Dec):

- default Value 1
- 0 – Unsolicited Report disabled
- 1 – Unsolicited Report enabled

Parameter No. 7 – Endpoint 3 – Unsolicited Report

Available configuration parameter (data type is 1 Byte Dec):

- default Value 1
- 0 – Unsolicited Report disabled
- 1 – Unsolicited Report enabled

Parameter No. 8 – Endpoint 4 – Unsolicited Report

Available configuration parameter (data type is 1 Byte Dec):

- default Value 1
- 0 – Unsolicited Report disabled
- 1 – Unsolicited Report enabled

Parameter No. 9 – Endpoint 5 – Unsolicited Report

Available configuration parameter (data type is 1 Byte Dec):

- default Value 1
- 0 – Unsolicited Report disabled
- 1 – Unsolicited Report enabled

Parameter No. 10 – Endpoint 6 – Unsolicited Report

Available configuration parameter (data type is 1 Byte Dec):

- default Value 1
- 0 – Unsolicited Report disabled
- 1 – Unsolicited Report enabled

Parameter No. 11 – Endpoint 7 – Unsolicited Report

Available configuration parameter (data type is 1 Byte Dec):

- default Value 1
- 0 – Unsolicited Report disabled
- 1 – Unsolicited Report enabled

Parameter No. 12 – Endpoint 8 – Unsolicited Report

Available configuration parameter (data type is 1 Byte Dec):

- default Value 1
- 0 – Unsolicited Report disabled
- 1 – Unsolicited Report enabled

Parameter No. 13 – Endpoint 9 – Unsolicited Report

Available configuration parameter (data type is 1 Byte Dec):

- default Value 1
- 0 – Unsolicited Report disabled

- 1 – Unsolicited Report enabled

Parameter No. 14 – End point 10 – Unsolicited Report

Available configuration parameter (data type is 1 Byte Dec):

- default Value 1
- 0 – Unsolicited Report disabled
- 1 – Unsolicited Report enabled

Parameter No. 15 – Random ID Enable

Available configuration parameter (data type is 1 Byte Dec):

- default Value 0
- 0 – Random ID disabled
- 1 – Random ID enabled

If Random ID is disabled, the Weather Station USB Key can receive data from multiple 433 MHz Sensors on the same Channel. If the Random ID is enabled, the USB Key can receive data from only one sensor on the same channel. If the USB Key does not receive a data from a sensor on a specific channel for more than 2.5 hours, it clears the Random ID of the device and waits for a new ID. If you replace the batteries in the modules, the Random ID will change. If you want that the USB Key accept a module immediately, set the Parameter No. 15 to "0" and in the next step again to "1".

Parameter No. 250 – Unsecure / Secure Inclusion

Available configuration parameter (data type is 1 Byte Dec):

- default Value 0
- 0 – Unsecure Inclusion
- 1 – Secure Inclusion

The Weather Station Key supports both, the secure and unsecure inclusion. Even if the main controller does not support security command classes, the Key could be included as unsecure and keep all the functionality. By default, the Key includes as unsecure. To include the Key as secure follow the procedure:

- Include the Key into the main controller
- Set the parameter 250 to the value "1"
- Enable add/remove mode on main controller ,
- Hold service button S between 1.5 and 4 seconds to exclude the module
- If the exclusion of the module was successful, the LED on the module starts blinking
- Unplug the module out of the power supply
- enable add/remove mode on main controller
- Plug the module into the power supply to star auto-inclusion
- Now the module should be included as secure

The same procedure is to include the module as unsecure.

Safety Procedure

In the case of lost connection between the 433 MHz Wireless Sensor and the Weather Station USB Key (more than 15 minutes of lost connection), the module will set Sensor values to extreme values. (Temperature = -199.0 °C, Velocity = 88.00 m/s, Rain = 300.00 mm/h, Humidity = 100 % or Direction = 0.0°), so that the associations and scenarios are triggered to lower the chance of potential damage.

If the Weather Station USB Key lose the power supply (or any other reason reset the Key), the Key will not report Sensor Values to the main controller until new data is received or maximum 240 seconds. If after 240 seconds, the Key still does not have new data from the sensor, it will set the sensor values to extreme values.

On each End point we can get battery level from corresponding sensor. On the Root device is a battery level from the sensor with the lowest battery level.

Technical Specifications

Weather station

Dimensions (WxHxD)	460x120x430mm
Weight	2 kg

USB Key

Power supply	USB Power Supply, 5V DC
Operation temperature	-10 ~ +40°C
Distance to Cockpit	up to 30 m indoors (depending on building materials)
Distance to 433Mhz Sensors	up to 100 m (depending on building materials)
Dimensions (WxHxD)	79x16x24mm
Electricity consumption	0,3 W

433MHz Sensors

Battery's	2 x UM-3 or "AA" size 1.5 V
Operation temperature	-10 ~ +60°C
Distance to USB Key	up to 100 m (depending on building materials)
Receiving Cycle	Remote Thermo/Hygro - Sensors cca. 45s Rain Gauge cca. 183s Wind Sensor cca. 33s
Temperature Accuracy	+/-1°C or +/-2°F
Humidity Accuracy	+/-5%
Wind Speed Accuracy	+/- (2mph + 5%)
Wind Direction Accuracy	+/-11.25°

Wave Device Class:

ZWAVEPLUS_INFO_REPORT_ROLE_TYPE_SLAVE_ALL
WAYS_0N
GENERIC_TYPE_SENSOR_MULTILEVEL
SPECIFIC_TYPE_ROUTING_SENSOR_MULTILEVEL

Wave Supported Command Classes:

COMMAND_CLASS_ZWAVEPLUS_INFO_V2
COMMAND_CLASS_DEVICE_RESET_LOCALLY_V1
COMMAND_CLASS_MANUFACTURER_SPECIFIC_V2
COMMAND_CLASS_POWERLEVEL_V1
COMMAND_CLASS_SECURITY
COMMAND_CLASS_FIRMWARE_UPDATE_MD_V2

Z-Wave Securely Supported Command

Classes:

COMMAND_CLASS_VERSION_V2
COMMAND_CLASS_SENSOR_MULTILEVEL_V7
COMMAND_CLASS_MULTI_CHANNEL_V4
COMMAND_CLASS_ASSOCIATION_V2
COMMAND_CLASS_MULTI_CHANNEL_ASSOCIATION_V3
COMMAND_CLASS_ASSOCIATION_GRP_INFO_V2
COMMAND_CLASS_CONFIGURATION
COMMAND_CLASS_BATTERY
COMMAND_CLASS_MARK
COMMAND_CLASS_BASIC

Endpoint 1, 2, 3, 4, 5, 6, 7, 8, 9, 10

Device Class:

ZWAVEPLUS_INFO_REPORT_ROLE_TYPE_SLAVE_ALL
WAYS_0N
GENERIC_TYPE_SENSOR_MULTILEVEL
SPECIFIC_TYPE_ROUTING_SENSOR_MULTILEVEL

Command Classes:

COMMAND_CLASS_ZWAVEPLUS_INFO_V2,
Securely Supported Command Classes:
COMMAND_CLASS_VERSION_V2
COMMAND_CLASS_SENSOR_MULTILEVEL_V7
COMMAND_CLASS_ASSOCIATION_V2
COMMAND_CLASS_MULTI_CHANNEL_ASSOCIATION_V3
COMMAND_CLASS_ASSOCIATION_GRP_INFO_V2
COMMAND_CLASS_BATTERY
COMMAND_CLASS_MARK
COMMAND_CLASS_BASIC

Remote Weather Sensors

The remote weather sensors include a thermo-hygrometer, anemometer (wind sensor) and rain sensor. All data collected by the sensors are transmitted to the Weather Station Key by wireless RF, with a range up to 100 meters (open area). The Weather station Key supports a maximum of 2 thermo-hygrometers, allowing 2 channels of temperature/humidity display (Ch1 and Ch2).



Setting up the Remote Weather Sensors

Before starting up the Weather Station Key, setup all the remote sensors first.

When placing the sensors, make sure that they are within receiving range of the console unit. Ideally, they should be within the line of sight of the console unit. Transmission range may be affected by trees, metal structures and electronic appliances. Test reception before permanently mounting your weather station.

Also make sure that the sensors are easily accessible for cleaning and maintenance.

The remote sensors should be cleaned on a weekly basis, since dirt and debris will affect sensor accuracy.

Setting up the Thermo-Hygro Sensor(s)

1. Release the latch at the base of the thermo-hygro sensor.
2. Set the channel with a slide switch to Ch1 or Ch2 (Channel has to be selected before inserting a battery's)
3. Insert two 2 x UM-3 or "AA" size 1.5 V batteries.
4. Use a pin to press the "RESET" key which is in the battery compartment of thermo-hygro sensors after LED flash.
5. Replace the latch and mount the unit at desired location.

Placement Tips:

- The thermo-hygro sensor should be in an area with free air circulation and sheltered from direct sunlight and other extreme weather conditions. Place the unit in a shaded area, such as under a roof.

- Avoid placing the sensor near sources of heat such as chimneys.

- Avoid any areas which collect and radiate heat in the sun, such as metal, brick or concrete structures, paving, patios and decks.

- Ideally, place the sensor above natural surfaces such as a grassy lawn.

- The international standard height for measurements of air temperature is at 1.25m (4 ft) above ground level.

Setting up the Rain Sensor

1. Unlock the funnel-shaped top of the rain sensor by turning both knobs on the sides of the rain sensor in an anti-clockwise direction.
2. Lift the top off the base and insert two 2 x UM-3 or "AA" size 1.5 V batteries into the battery holder.
3. Replace the lid and secure into place by turning the knobs clockwise.
4. Place the rain sensor in a location such that precipitation can fall directly into the sensor, ideally 2-3 ft above the ground. It may be secured into place by using the four screws provided.
5. The sensor must be accurately levelled for optimum performance. To check if the sensor is levelled, remove the lid and check if the ball bearing inside is at the midpoint of the leveller. Additionally, a bubble level or carpenter's level may be used.
6. Attach the protective screen onto the top of the lid. The screen will prevent any debris entering the sensor.

Placement Tips:

- The rain sensor should be placed in an open area away from walls, fences, trees and other coverings which may either reduce the amount of rainfall into the sensor, deflect the entry of wind - blown rain, or create extra precipitation runoff. Trees and rooftops may also be sources of pollen and debris.

- To avoid rain shadow effects, place the sensor at a horizontal distance corresponding to two to four times the height of any nearby obstruction.

- It is important that rain excess can flow freely away from the sensor. Make sure that water does not collect at the base of the unit.

- The rainfall measurement mechanism utilizes a magnet; hence do not place any magnetic objects around the proximity of the sensor.

Setting up the Anemometer (Wind Sensor)

1. Assemble the wind cups and wind vane to the anemometer arm
2. Attach the assembled anemometer to the base.
3. Insert two 2 x UM-3 or "AA" size 1.5 V batteries into the battery holder in the base and connect the second battery to the solar panel connector.
4. Mount the anemometer onto a vertical surface, using the fittings provided.

Placement Tips:

- Check that wind can travel freely around the anemometer and is not distorted by nearby buildings, trees or other structures.

- For better results, place the anemometer at least 3 m above local structures and obstacles. The ground creates a frictional effect to wind flow and will attenuate readings.

- Aim for maximum exposure of the anemometer to the commonest wind directions in your area.

- The official mounting location for anemometers is 10m (33 ft) above ground level in a clear unobstructed location.

Maintenance

Changing Batteries

The battery statuses of the sensors are checked every hour. If the low battery indicators light up, replace the batteries for the corresponding unit immediately.

Changing Batteries for the Remote Sensors

1. Replace the batteries following the setup instructions for the corresponding sensor.
2. When the batteries are properly installed, the sensor will resume sending signals to the main console unit.

Cleaning

The Weather Station Key and outer casings for the remote sensors can be cleaned with a damp cloth. Small parts can be cleaned with a cotton tip or pipe-cleaner.

Never use any abrasive cleaning agents and solvents. Do not immerse any units with electronic parts in water or under running water.

Anemometer

- Check that the wind vane and wind cups can spin freely and are free from dirt, debris or spider webs.

Rain Sensor

Like all rain gauges, the rain sensor is prone to blockages due to its funnel shape. Checking and cleaning the rain sensor from time to time will maintain the accuracy of rain measurements.

- Detach the protective screen and lid. Remove any dirt, leaves or debris by cleaning the items with soapy water and a damp cloth. Clean small holes and parts with a cotton tips or pipe-cleaner.

- Look out for spiders or insects that might have crawled into the funnel.

- Also clean the swinging mechanism with a damp cloth.

Troubleshooting

The Weather Station Key will not receive any data when the wireless link with the Sensor is lost.

Check or replace the batteries for the corresponding sensor.

If the above does not solve the problem, check the wireless transmission path from the corresponding sensor to the main console unit and change their locations if necessary.

Although wireless signals can pass through solid objects and walls, the sensor should ideally be within the line of sight of the console unit.

The following may be the cause of reception problems:

- Distance between remote sensor and Weather Station Key is too long. (Maximum transmission distance in open area conditions is up to 100 m.)

- Signal shielding materials such as metal surfaces, concrete walls or dense vegetation in the path of transmission.

- Interferences from wireless devices (such as cordless phones, radio headsets, baby listening devices) and electronic appliances.

The weather readings do not correlate with measurements from TV, radio or official weather reports

Weather data can vary considerably due to different environmental conditions and placement of weather sensors.

Check the placement tips included in this manual to site your sensors in the best possible way.

PRECAUTIONS

This product is engineered to give you years of satisfactory service if you handle it carefully. Here are a few precautions:

1. Do not immerse the unit in water.
2. Do not clean the unit with abrasive or corrosive materials. They may scratch the plastic parts and corrode the electronic circuit.
3. Do not subject the unit to excessive force, shock, dust, temperature or humidity, which may result in malfunction, shorter electronic life span, damaged battery and distorted parts.
4. Do not tamper with the unit's internal components. Doing so will invalidate the warranty on the unit and may

cause unnecessary damage. The unit contains no user-serviceable parts.

5. Only use fresh batteries as specified in the user's manual. Do not mix new and old batteries as the old ones may leak.

6. Always read the user's manual thoroughly before operating the unit.

CAUTION

- The content of this manual is subject to change without further notice.

- Due to printing limitation, the units shown in this manual may differ from the actual units.

- The contents of this manual may not be reproduced without the permission of the manufacturer.

This user manual is subject to change and improvement without notice.

NOTE: User manual is valid for module with SW version S2 (SW version is part of P/N!) Example: P/N: NEWHZEEx Hxs2Px

Important disclaimer

Wireless communication is inherently not always 100% reliable, and as such, this product should not be used in situations in which life and/or valuables are solely dependent on its function.

As well, Weather Station Sensors can lose communication with the Weather Station Key. The caution should be taken when using the data from the sensors for controlling other devices using scenarios or associations.

Warning!

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities.

Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being. When replacing old appliances with new ones, the retailer is legally obligated to take back your old appliance for disposal at least for free of charge.



Cockpit Smart Home d.o.o.

Ulica Klementa Jurga 007

5250 Slokan, Slovenia

Web: www.yourcockpit.biz

Tel: +386 5 335 95 00

Date: 04.03.2018

Document: Cockpit SL_Weather Station_user manual_V1.2B_eng